Printable Version



Roadster Hood Actuator Switch Failure

Rate This Article	(Average Rating: No Rating)	Version 2	Language	English	Show Properti
	(3 -	

Summary:

BRP has noticed an increase in claims for the RT hood actuator switch.

Type: General

TST Detail:

Switch inspection reveals the contact points inside the switch are exposed to high amperage. This causes an intermittent or permanently bad contact.


Inspect the hood actuator itself to see if the lever it pushes against is in-line and not obstructed. This could also happen if the front cargo is over packed and the pressure pressing up against the mechanism is beyond what the actuator can push and the switch gets too much amperage.

Here are 2 quick way to diagnose the hood actuator switch (notice 2010 is different from 2011/12/13): In both tests the hood actuator switch should be pressed to close the circuit, insert a screw driver as shown here.



2010


- 1. Using a multimeter set to Ohms take readings in the front bin area.
 - a. Disconnect the hood actuator and remove the green terminal lock using a small screw driver.b. Remove fuse box cover and remove load shedding relay.c. Expected resistance is less than 2 Ohms



2011/12/13


- 1. Using a multimeter set to Ohms take readings in the front bin area.
 - a. Disconnect the hood actuator and remove the green terminal lock using a small screw driver.b. Remove left fuse box cover and remove F7 fuse (10 amp).

 - c. Expected resistance is less than 2 Ohms




- 2. Access the console harness connector on the LH mid section.
 - a. Remove the LH lateral panel and the acoustic panel.
 - b. Disconnect the console harness from the main harness.
 - c. Set the multimeter to Ohms and measure the resistance between the illustrated terminals
 - d. Expected resistance is less than 2 Ohms

Traduire



2011/12/13



Attachment:

First Published By: Dany Davey on 2013-10-25 Last Modified By: Dany Davey on 2013-10-25