

** SOLUTION **

Title	Diagnostic Trouble Codes (DTC) P2080, P2084, P242B Lighting The Malfunction Indicator Lamp (MIL) - US14+OBD16, US17+OBD16, And US17+OBD18 Emissions, Model Years 2017 To 2019
Mack Models	
Mack Model	LR, MRU - TerraPro, AN - Anthem, CHU - Pinnacle, Axle back, CXU - Pinnacle, Axle front, GU - Granite
Volvo Models	
Volvo Model	VNL, VNM, VNR, VNX, VAH, VHD
Emission Standard	
Emission Standard	US14+OBD16, US17+OBD16, US17+OBD18
Engine family	
Engine family	11L Engine, 13L Engine, MP7, MP8
** SOLUTION **	
Cause	Diagnostic Trouble Codes (DTC) P2080, P2084, and/or P242B may set after key off. It has been found that this may be due to incorrect calculation of the "soak" time of ambient temperature.
	Vehicles may exhibit the MIL and one or any combination of the above fault codes from the Engine Control Module (EMS), as well as one or more of the symptoms below:
	• No Diesel Exhaust Fluid (DEF) Dosing
	- DEF will not be injected with these faults active.
	Unable To Complete A Parked Regeneration
	- Aftertreatment Hydrocarbon Injector (AHI) injection will not take place with these faults active.
	• Parked Regeneration Runs Too Long, And Does Not Complete
Solution	WARNING



- 1. Allow the vehicle to sit until the engine and exhaust have reached ambient (air) temperature.
- 2. Turn the ignition to ON, engine OFF.
- 2. Using Premium Tech Tool (PTT), run either of the operations below:
 - 2545-08-03-02 Exhaust Aftertreatment Diagnostics, option A
 - This will provide a numerical view of exhaust temperatures.
 - 2589-08-03-02 Exhaust Aftertreatment System, Service Regeneration
 - This will provide a graphical view of exhaust temperatures.
- 3. Ensure that the sensor readings are within 10 °C (18 °F) of one another before starting the engine.
- 4. Start the engine.
- 5. Monitor exhaust temperatures on PTT:
 - The sensor temperatures should rise in the order of 1, 2, 3 as shown below after starting the engine.
- 6. Evaluate results:

• If the sensor readings are equal at ambient temperature and rise in the correct order when the engine is running: No further fault tracing should be performed. Clear the DTCs and return the vehicle to service.

• If one or more sensors are displaying a different reading from the others or are spiking instead of smoothly increasing with the engine running: The sensor(s) should be suspected to be faulty.

• If the temperature sensor values rise out of order: The sensors should be checked to ensure they are installed in the correct positions.

An example of proper temperature sensor function can be found below:



This CBR will be updated when new information is available.

Solution visibility	Dealer distribution
Function(s)/compone	nt(s) affected
Function affected	1 1 0 EMS, DEF Dosing, DOC, DPF
Function Group	
Function Group	254 catalytic converter; exhaust emission control equipment, 258 emissions after- treatment
Customer effect	
Main customer effect	regeneration, temperature, fault code/display
Fault Codes And Erro	or Codes
OBDII Diagnostic Trouble Codes (P, U, B Format)	P2080-64, P2084-64, P242B-64
Conditions	
Vehicle operating mode	on start-up, when stationary
Administration	
Author	UT0389H
Last modified by	RU4469V
Creation date	14-03-2017 20:03
Date of last update	04-10-2019 17:10
Review date	15-06-2017 00:06
Status	Published
Average score	4
Number of scores	4
NA_Reviewer	Jeremy Newton

UNCONTROLLED COPY. Printed document is for temporary use only and should not be retained.