



Subject: Replacing Double Groove Belt with Single Groove Matched Belts							
Field Change Program: Procedure	Procedure Number: 16-41	Revision:	<b>Date:</b> 02/21/2020				
Coach Section: 16- Heating & A/C	<b>P/N:</b> 08-27-1357		Type: Product Improvement				

## **Application:**

Coach Model	Model Year	VIN
J4500	2019 - 2020	69367 - 69905

# **MARNING**

Read this entire procedure before beginning work.

Use Safe Shop Practices at All Times.

To avoid personal injury:

- a. Proper Personal Protective Equipment (PPE) must be worn. Safety glasses and protective gloves are required for working with DEF Fluid.
- b. Turn the main battery disconnect switch to the OFF position.
- c. Ensure that both the front and the rear wheels are chocked.
- d. Position the ENGINE RUN and ENGINE START switches on the engine compartment remote control box to the OFF position.
- e. Allow enough time for components to cool down <u>prior to working</u> in the engine compartment.



### 1.0 Description

This procedure outlines steps to replace the double groove belt on the AC compressor with single groove matched belts.

## 2.0 Material requirements

ITEM	PART NO	QTY	U/M	DESCRIPTION
1	08-27-1538	1	EA	Belt-A/C Compr, 5VX, matched set

### 3.0 Special Tools

Pry bar.

4 X 4 wooden block.

Belt alignment tool (Vendor: VibrAlign, VPN: 100-BH2)



#### 4.0 Procedure


Open the engine door using the latch behind the curbside service door.




Rotate the lever counter clockwise




Lift the AC compressor unit from the curbside service door using a prybar. Place a  $4 \times 4$  wooden block on the frame as a support for the prybar. Hold the prybar to remove tension on the belt.



Remove and discard the double groove belt on the AC compressor.




Install single groove matched belts, MCI P/N: 08-27-1538, as shown below.





#### 5.0 Verification

Use the belt alignment tool to verify alignment of AC compressor pulley to the pulley on the crankshaft following the instructions in the maintenance manual section 16A-2.



End of the procedure