## Surface-Flush Door Handle Does Not Retract When Vehicle Locked

| Topic number      | LI72.10-P-075291   |
|-------------------|--|
| Version           | 2  |
| Function group    | 72.10 - Front door   |
| Date              | 2/13/23  |
| Validity          | MODEL 223 with code 889 up to manufacturing date 2 July 2022.                        |
|                   | MODEL 295 with code 889 up to manufacturing date 2 July 2022.                        |
|                   | MODEL 296 with code 889 up to manufacturing date 2 July 2022.                        |
|                   | MODEL 297 with code 889 up to manufacturing date 2 July 2022.                        |
| Reason for change | Validity adapted: Model series X296 added; Cause adapted: Fault code B185E96 amended |

## Complaint

The surface-flush door handle sometimes does not retract when the vehicle is locked.

It is only after repeated locking operation that the problematic door handle retracts.

#### Cause

Motor fault detection (FC B185E96 or B185D96) is triggered in the bearing bracket electronics of the surface-flush door handle (A17/x) during the retracting movement and an adjustment for this cycle is prevented.

### Remedy

Replace bearing bracket of surface-flush door handle on problematic door.

| WIS-References    |   |  |  |  |
|-------------------|---|--|--|--|
| Document number   | Title   | Note   |  |  |
| AR72.10-P-4012S   | Remove/install front door handle bearing bracket        | Model 223 except code Z07 (B7 armoring for special protection version) |  |  |
| AR72.12-P-4012S   | Remove/install door handle bearing bracket of rear door | Model 223 except code Z07 (B7 armoring for special protection version) |  |  |
| AR72.10-P-4012EQS | Remove/install front door handle bearing bracket        | Model 295, 296, 297  |  |  |
| AR72.12-P-4012EQS | Remove/install door handle bearing bracket of rear door | Model 295, 296, 297  |  |  |

# XENTRY TIPS

| Symptoms                                       |  |
|--|--|
| Body > Door/Flap > Door > Door handle > Jammed |  |

| Operation numbers/damage codes |                |      |             |      |  |  |  |
|--------------------------------|----------------|------|-------------|------|--|--|--|
| Op. no.                        | Operation text | Time | Damage code | Note |  |  |  |
|                                |                |      | 80A0D73     |      |  |  |  |
|                                |                |      | 80N0D73     |      |  |  |  |
|                                |                |      | 80A0E73     |      |  |  |  |
|                                |                |      | 80N0E73     |      |  |  |  |