

Installation and Conversion Instructions

Panamera (971) 3/17 ENU 2635

Sports Tailpipe - Silver (0P3)/Black (0P6)

- Revision: This bulletin replaces bulletin Group 2 3/17, dated September 11, 2017.
- Model Year: As of 2017 up to 2020
- Vehicle Type: Panamera 4S/Panamera Turbo/Panamera Turbo S E-Hybrid including related Executive and Sport Turismo variants
- Information:

Retrofitting

Information






Figure 1

Notes: The tailpipes for the standard exhaust system on the vehicles specified above can be replaced by new sports tailpipes in Silver chrome-plated look (OP3) or Black chrome-plated look (OP6) (\Rightarrow *Figure 1*).

The sports tailpipes can be retrofitted worldwide.

From June 2017, the sports tailpipes are also available straight from the factory for new vehicles by requesting the relevant optional equipment.

Parts Info:	971.044.200.A	\Rightarrow Sports tailpipe –silver chrome-plated–, set
	971.044.200.B	\Rightarrow Sports tailpipe – black chrome-plated–, set

Parts list:

2635

2

Panamera (971)

ENU

3/17



Figure 2

9A7.253.823.30 ¹	1 x	Sports tailpipe, silver chrome-plated, outer left \Rightarrow Figure 2-1-
9A7.253.823.35 ¹	1 x	Sports tailpipe, silver chrome plated, inner left \Rightarrow Figure 2-2-
9A7.253.824.35 ¹	1 x	Sports tailpipe, silver chrome-plated, inner right \Rightarrow Figure 2-3-
9A7.253.824.30 ¹	1 x	Sports tailpipe, silver chrome-plated, outer right \Rightarrow Figure 2-4-
9A7.253.823.40 ¹	1 x	Sports tailpipe, black chrome-plated, outer left \Rightarrow Figure 2-5-
9A7.253.823.45 ¹	1 x	Sports tailpipe, black chrome-plated, inner left \Rightarrow Figure 2 -6-
9A7.253.824.45 ¹	1 x	Sports tailpipe, black chrome-plated, inner right \Rightarrow Figure 2-7-
9A7.253.824.40 ¹	1 x	Sports tailpipe, black chrome-plated, outer right \Rightarrow Figure 2-8-
9A7.008.019.00	4 x	Countersunk screw, M6 x 12 PA \Rightarrow Figure 2 -9-
N.903.425.02	4 x	Speed nut, M6 x 19.5 x 18 – VW602 49 <i>⇒ Figure 2</i> -10-

¹ ONLY contained in respective set!

Tequipment

	Information ONLY in the event of repairs/replacement: Items WITHOUT a part number in the parts list can be found/ordered from the Porsche Electronic Parts Catalog = PET.
	Check model year and vehicle equipment (I-no.) in the standard catalog!
Tools:	Nr.90 Pos.1 - Torque wrench Flashlight
Installing:	1 Preparatory work
	1.1 Drive the vehicle onto a lifting platform and connect the battery charger. \Rightarrow Workshop Manual '2X00IN Battery trickle charging'

1.2 Raise the vehicle. \Rightarrow Workshop Manual '4X00IN Lifting the vehicle'

Hot components

- Risk of burns
- \Rightarrow Let hot components cool down.
- \Rightarrow Wear personal protective gear.
 - 1.3 Remove standard tailpipes (⇒ *Figure 4* (*Panamera Turbo*)). ⇒ Workshop Manual '263519 Removing and installing tailpipe cover'
 - 1 Standard tailpipes right-hand side
 - 2 Countersunk screw, M6 x 12
 - **3** Speed nut, M6 x 19.5 x 18 VW602 49
 - 1.4 Replace snap nut, M6 x 19.5 x 18 VW602
 49 (⇒ Figure 4 (Panamera Turbo)-3-) if necessary.
 - 2 Installing sports tailpipe
 - 2.1 Slide the new sports tailpipes onto the relevant rear silencer stub pipes as far as the screw point and preassemble by fitting a new countersunk screw, M6 x 12 hand-tight.




Figure 4 (Panamera Turbo)



Information

If the sports tailpipes have to be moved to the right or left, this can only be performed via the connecting strut between the rear mufflers (see also: \Rightarrow *Workshop Manual '263319 Removing and installing rear muffler*).

- 2.2 Check that the gap = "dimension Z" (⇒ Figure 5 Z-) between the new sports tailpipes and exhaust system cover (rear apron left and right side of vehicle) is symmetrically constant.
 - dimension Z symmetrically constant all the way around with respect to exhaust system cover dimension X – equal projection (right side of

vehicle)

Re-align sports tailpipes if necessary.



Information

The tailpipes are adjusted in X direction using the slots in the tailpipe.

Check that the sports tailpipes project equally




Figure 5

- = "dimension X" with respect to the rear apron (left and right side of vehicle \Rightarrow Figure 5 X -). Re-align sports tailpipes if necessary.
- 2.4 Tighten countersunk screw (M6 x 12) on the sports tailpipe. Tightening torque 8 Nm (6 ftlb.) +/-1 Nm (+/-0.5 ftlb.)
- 3 Concluding work

2.3

- 3.1 Disconnect the battery charger. \Rightarrow Workshop Manual '2X00IN Battery trickle charging'
- 3.2 Lower the lifting platform and remove the vehicle.
- 26 35 20 00: -Removing and installing tailpipes (4 x)-Includes: Removing standard tailpipe (4 x) and installing new sports tailpipe (4 x). Aligning new sports tailpipe (4 x) with respect to rear apron.

Important Notice: Technical Bulletins issued by Porsche Cars North America, Inc. are intended only for use by professional automotive technicians who have attended Porsche service training courses. They are written to inform those technicians of conditions that may occur on some Porsche vehicles, or to provide information that could assist in the proper servicing of a vehicle. Porsche special tools may be necessary in order to perform certain operations identified in these bulletins. Use of tools and procedures other than those Porsche recommends in these bulletins may be detrimental to the safe operation of your vehicle, and may endanger the people working on it. Properly trained Porsche technicians have the equipment, tools, safety instructions, and know-how to do the job properly and safely. Part numbers listed in these bulletins are for reference only. The work procedures updated electronically in the Porsche PIWIS diagnostic and testing device take precedence and, in the event of a discrepancy, the work procedures in the PIWIS Tester are the ones that must be followed.

© 2021 Porsche Cars North America, Inc.

Labor time: 55 TU

Tequipment