



Volvo Chassis LED Headlights Conversion Programming Procedure - Model VNL



> Internal Content

After the correct LED Headlights have been installed the Light Control Module (LCM) MID216 parameters will need to be changed to reflect the LED Headlight installation. This is done by performing the accessory kit operation found in TDP (Accessory kit # [85141183](#)). (**NOTE:** Accessory Kit # [85141183](#) will need to be manually entered). Once the accessory kit operation has been completed program the LCM (MID216).



Tags

[k32353850](#)[volvo](#)[led](#)[headlights](#)

Related links and attachments

No links or attachments available



Feedback

[Give feedback](#)

to help improve the content of this article