



Volvo Chassis Ghost Codes Due To Poor Grounding



> **Internal Content**

Remove the anti corrosive coating from all terminal connections. Install with the proper torque and reapply the anti corrosive.

 Tags [k42629913](#)

Related links and attachments

No links or attachments available

Feedback

[Give feedback](#)

to help improve the content of this article