

03-085: Bendix BlindSpotter Aftermarket Install

10/19/2022

 [Edit](#)  [Clone](#)

03-085

Bendix BlindSpotter Aftermarket Install

Subject

Bendix BlindSpotter Aftermarket Install

Whats New Abstract

This is a follow-up bulletin to shortage bulletin S017. Parts kits are now available to install the Bendix Side Collision Mitigation Radar system (BlindSpotter) on chassis that were delivered with a prewire sales code due to parts shortages. Ordering and installation procedures are included.

Condition

Certain chassis were delivered with a prewire setup for the Bendix Side Collision Mitigation Radar (BlindSpotter) system due to a parts shortage. Parts are now available to install the complete system in these vehicles.

Chassis Affected

Model Year 2023 337, 348, 389, 520, 536, 537, 548, 567, and 579 chassis built from 5/23/2022 through current with Bendix Side Collision Mitigation Radar (BlindSpotter) "Prewire" specified on the vehicle sales order.

Action

Information Only

Please see procedure section of this bulletin for details on how to install the parts to complete the prewired Bendix BlindSpotter system.

Situation

Model Year 2023 337, 348, 389, 520, 536, 537, 548, 567, and 579 chassis built from 5/23/2022 through current with Bendix Side Collision Mitigation Radar (BlindSpotter) "Prewire" specified on the vehicle sales order.

Warranty

There is no warranty offered for the purchase and/or installation of these Bendix BlindSpotter kits. Purchase and installation will be completely paid by the customer who owns the vehicle.

Parts

Parts are available from PACCAR Parts.

Quantity	Part Number	Description
1	K252262A000	Single 250K sensor for 1.9m medium duty chassis.
1	K252261A000	Single 500K sensor for 1.9m *OR* 2.1m chassis *OR* Model 520 with single RH or LH sensor.
1	K252260A000	Dual 500K sensors for Model 520 (RH - lower level, LH - higher level).

Procedure

Please follow your dealership's safety procedures and precautions to ensure the vehicle can be safely repaired and maintained.

If you already have the correct parts kit, please see the Links section for the installation procedure. Also, see the Links section for the Bendix BlindSpotter manual.

If you do not yet have the parts kit needed, please see the Parts section for kit numbers, and place your kit order per the following:

Place parts order with PACCAR Parts:

- oSubmit a 'Place an Order' TCS365 case
- oSelect Case Category as "Pre-Wire"
- oProvide Kit Part Number
- oProvide Chassis Number invoiced with "Pre-Wire" code
- oProvide the Dealer PO Number

Kits are specifically for trucks with the Side Radar Pre-Wire ONLY.

Attachments

[Bendix BlindSpotter Installation Procedure](#)

[Bendix BlindSpotter manual](#)

Authored by D. Cook