



# Tech Tips

TT 37-12-04

Date: September 14, 2012

## 2011-2013 Touareg – Correct Vacuum Line Connections at Coolant Shut-Off Valve N82 and Change Over Valve N180

After completing repairs that require removal of the vacuum lines at coolant shut off valve N82 and change over valve N180, ensure vacuum lines are correctly reinstalled. At the N180, source vacuum must be connected to the bottom connection and the vacuum line to the N82 must be connected to the upper connection.

