

2015 Volkswagen Jetta Sedan Maintenance Schedule For USA
2.0L MPI Engine



Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
Airbag system: Perform visual inspection (Every 1 year regardless of mileage)	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *	1, *
Air filter element and snow filter: Replace and clean housing (Every 6 years regardless of mileage)						7, *						7, *
Battery: Check		X		X		X		X		X		X
Body: Visual inspection for corrosion				X				X				X
Brake pads: Check thickness and brake disc condition. Look for contact pattern and corrosion of brake discs (front and rear)	X		X		X		X		X		X	
Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition front and rear. Look for contact pattern and corrosion of brake discs, and check brake fluid level subject to abrasion		X		X		X		X		X		X
Brake fluid and clutch unit: Change fluid (Every 3 years regardless of mileage and every 2 years after)			4, *		4, *		4, *		4, *		4, *	
Coolant level and frost protection: Check				X				X				X
CV joints: Check for leaks and damage				X				X				X
Door checks and mounting pins: Lubricate				X				X				X
Dust and pollen filter: Replace (Every 2 years regardless of mileage)		2, *		2, *		2, *		2, *		2, *		2, *
Engine: Change oil and replace oil filter	X	X	X	X	X	X	X	X	X	X	X	X
Engine and engine compartment components: Check (from above) for leaks and damage				X				X				X
Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots				X				X				X
Exhaust system: Check for leaks, damage and secure fittings				X				X				X
Headlights: Check adjustment				X				X				X
Interior lighting and glove box lights, cigarette lighter / power outlets, horn, and all warning lamps: Check				X				X				X
Lighting: Front and rear lights, luggage compartment lighting, turn signals, hazard warning lights: Check				X				X				X
Power steering: Check oil level				X				X				X

2015 Volkswagen *Jetta Sedan* Maintenance Schedule For USA
2.0L MPI Engine



Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K

* Carefree Maintenance Program - Time dependent items will be included in scheduled maintenance intervals if applicable

1. Every 1 year, regardless of mileage: Perform visual check of airbag system
2. Every 2 years, regardless of mileage: Dust and pollen filter: Replace **(if applicable)**
3. Every 2 years, regardless of mileage: Tire filler bottle in the tire mobility kit: Check **(observe expiration date) (if applicable)**
4. At the 3 year mark, then every 2 years regardless of miles driven: Brake fluid and clutch unit: Replace fluid
5. Every 4 years, regardless of mileage: Tire filler bottle in the tire mobility set: Replace **(Observe expiration date)**
6. Every 4 years regardless of mileage: Replace spark plugs
7. Every 6 years regardless of mileage: Air filter element and snow filter: Replace element and clean screen and housing **(if applicable)**

© 2014 Volkswagen Group of America, Inc.

All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice.

No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.

Posted: June 2014