

Reference	SSM72234
Models	Discovery Sport / L550
Title	SD Card Check
Category	Electrical
Last modified	27-Apr-2015 00:00:00
Symptom	204000 Instrumentation
Attachments	SD Card Inspection1.pdf

ContentIssue

1. Navigation system fails to read the SD card

Cause

1. SD card locked – see attachment.
2. SD card installed in the incorrect orientation – see attachment.

Action

Note: Set the time clock & date prior to activation.

1. Ensure the SD card is in the unlocked position (see attachment).
2. Ensure the card is correctly located with the label facing down (see attachment).

Technicians - Please rate this SSM and provide comments so that future communications can be improved.

1 = Poor – Basic information provided – The SSM does not help me resolve the customer concern.

3 = Average – Adequate information provided – The SSM partially helps me resolve the customer concern.

5 = Excellent – All required information provided to resolve the customer concern.

SD Card Visual Inspection

LOCKING TAB

Unlocked (Correct)



Locked (Incorrect)



ORIENTATION

label facing down (Correct)



Label facing up (Incorrect)

