2017 Volkswagen *Jetta Hybrid* Maintenance Schedule For USA 1.4L Hybrid Engine



Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K	130K	140K	150K
Air filter element and snow sieve: Replace and clean housing (Every 6 years regardless of mileage)						6						6			
Battery: Check		Х		Х		Х		Х		Х		Х		Х	
Body: Visual inspection for corrosion				Х				Х				Х			
Brake pads: Check thickness and brake disc condition. Look for contact pattern and corrosion of brake discs (front and rear)	x		x		x		x		x		x		х		x
Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition front and rear. Look for contact pattern and corrosion of brake discs, and check brake fluid level subject to abrasion		x		x		x		x		x		X		x	
Brake fluid and clutch unit: Change fluid (Every 3 years regardless of mileage and every 2 years after)			3		3		3		3		3		3		3
Coolant level and frost protection: Check				Х				Х				Х			
CV joints: Check for leaks and damage				Х				Х				Х			
Dust and pollen filter: Replace (Every 2 years or 40,000 miles)				1				1				1			
Engine: Change oil and replace oil filter	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
Engine and engine compartment components: Check (from above) for leaks and damage				Х				Х				Х			
Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots				x				x				x			
Exhaust system: Check for leaks, damage and secure fittings				Х				Х				Х			
Headlights: Check adjustment				Х				Х				Х			
Hybrid components: Perform a visual inspection of high voltage components and the lines in the engine compartment and the rear of the vehicle for damage	x	x	x	x	x	x	x	x	x	x	x	х	х	x	x
Interior lighting and glove box lights, cigarette lighter / power outlets, horn, and all warning lamps: Check				Х				Х				Х			

2017 Volkswagen *Jetta Hybrid* Maintenance Schedule For USA 1.4L Hybrid Engine



Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K	130K	140K	150
Lighting: Front and rear lights, luggage compartment lighting,															
turn signals, hazard warning lights: Check				X				Х				Х			
Power steering: Check oil level				Х				Х				Х			
Ribbed belt: Check condition (if applicable)				Х				Х				Х			
Service interval display: Reset	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
Spark plugs: Replace				4				4				4			
Sunroof and panoramic sunroof: Check, clean, and lubricate (if applicable)				х				X				X			
Sunroof: Open sunroof and check front water drains and clean if necessary (if applicable)				x				x				X			
Test drive: Check braking, kickdown, steering, electrical, heating and ventilation systems, air conditioning, handling, and parking brake				x				x				x			
Tie rod ends: Check for excessive play and looseness, check boots				х				X				X			
Timing belt: Check (if replacement is not necessary, perform check every 20,000 miles after until replacement is necessary)															x
Coolant pump drive belt: Check (if replacement is not necessary, perform check every 20,000 miles after until replacement is necessary)															x
Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)		Х		х		Х		X		Х		X		Х	
Tire mobility kit: Check and observe expiration date on the tire filler bottle (Every 2 years regardless of mileage)		2		2		2		2		2		2		2	
Tire mobility kit: Replace tire filler bottle (Every 4 years regardless of mileage)				5				5				5			
Transmission: DSG (non Automatic): Change fluid and filter (if applicable)				х				х				х			
Underbody sealant: Inspect for damage				Х				Х				Х			

2017 Volkswagen <i>Jetta Hybrid</i> Maintenance Schedule For USA
1.4L Hybrid Engine

Miles	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K	130K	140K	150
Windshield washers, headlight cleaning system, and wiper blades: Check for damage and function, Check fluid level and add if necessary	x	x	x	х	x	x	x	x	x	x	x	x	x	x	х
1. Every 2 years or 40,000 miles: Dust and pollen filter: Rep	olace (i	f appli	cable)												
2. Every 2 years, regardless of mileage: Tire filler bottle in t	he tire	mobilit	y kit: C	heck (observ	ve exp	oiratior	n date)	(if ap	plicabl	e)				
3. At the 3 year mark, then every 2 years regardless of mile	s drive	n: Bral	ke fluid	and c	lutch u	nit: Re	place	fluid							
4. Every 4 years, regardless of mileage: Replace spark plu	gs														
5. Every 4 years, regardless of mileage: Tire filler bottle in t	he tire	mobilit	y set: I	Replac	e (Ob	serve	expira	tion d	ate)						
C. Evenu C.veere recordless of miles set Air filter element on	d snov	v sieve	: Repla	ace ele	ment a	and cle	ean scr	een an	d hous	sing (if	applic	able)			
b. Every 6 years regardless of mileage. All filler element an															
 Every 6 years regardless of mileage: Air filter element an © 2016 Volkswagen Group of America, Inc. 															