

Service

67/12 ENU 2706

2

AGM Battery Care and Maintenance: From Vehicle Delivery Until Sale (customer handover) (67/12)

Vehicle Type: Cayenne (92A)/Cayenne S (92A)/Cayenne GTS (92A)/Cayenne Turbo (92A)

Model Year: As of 2011

Concerns: AGM starter battery (referred to below simply as 'battery')

Situation: Support for the care and maintenance of the AGM starter battery (at the dealership):

From the time the vehicle is delivered to the Porsche Centre until it is handed over to the customer, the battery must be maintained and charged regularly, depending on use.



Information

The battery has a limited service life.

The service life of the battery is affected by:

- the driving conditions for the vehicle and
- thus, by the care and maintenance of the battery (trickle charging, etc.).

 \Rightarrow If a charger is not connected in order to trickle-charge the battery when the vehicle is idle for extended periods,

the battery life will be reduced considerably, thereby resulting in natural wear.

Please pass this information on to your customers.

Tools: 9818 - PIWIS Tester II

Recommended measuring devices, see ⇒ 10; chargers, see ⇒ ; trickle charging, see ⇒

Overview: **Brief overview** (instructions and overview of contents, \Rightarrow *Figure 1*):

1.) **Delivery** of the vehicle to the Porsche dealer.

See \Rightarrow 1 \Rightarrow Check condition of battery:

Condition of battery:

Not

OK.

111

Condition of battery:

OK.

After

using the vehicle

(Step 2.) 3.) 4.) or 5.), see below:


2706 ENU **67/12**

Technical Information

Step 6.) before cus	stomer handover.					
2.) Direct vehicle:	3.) Showroom vehicle:	4.) Stock vehicle:	5.) Stock Demo vehicle:			
Vehicle is handed over to customer within five days:	Vehicle remains in the showroom:	Vehicle is parked at a storage location:	Vehicle is used as a demonstration vehicle in the warehouse:			
see ⇒ 2	see ⇒ 3	see ⇒ 4	see ⇒ 5			
⇒	at the earliest 48 hours	before vehicle handover				
⇒ at the latest 36 hours before vehicle handover						
	to the customer (cus	tomer handover):				
↓ ↓.	L					
6.) Only if result of o	check is "Not OK":					
⇒ Replace bat	tery, see ⇒ 6					
7.) Charge and check the battery, see ⇒ 7.						
Recommendations for:						
⇒ Measuring equipment/ measuring devices , see ⇒ 10						
⇒ Chargers, see ⇒						
⇒ Trickle charging (p	ermanent), see \Rightarrow .					
Procedure for:						
⇒ Measurement and	documentation (in Chec	klist), see \Rightarrow 20.				
Additional step:						

Technical Information	Service				
	67/12 ENU 2706	2			

 \Rightarrow Read out values from PIWIS Tester II, see \Rightarrow .



67/12 ENU 2706

Upon delivery: 1 Vehicle is delivered to the Porsche Centre (\Rightarrow Figure

 \Rightarrow Voltage measurement to determine the quality of the battery:




Figure 2

Figure 3

1.1 For correct voltage measurement (incl. inactive period of 5 min.), engine/vehicle may only run for max. 3 min. for operational procedures, e.g. unloading from transporter, collecting from storage location ().

Figure 4

1.2 Observe battery inactive period (5 min.,) before measuring voltage.

Figure 5

- 1.3 Measure voltage using a suitable voltmeter (). Observe recommended devices, see Step \Rightarrow 10 and battery temperature (>= 10° C/50° F).
- 1.4 Evaluate measured voltage ():
 - If >= 12.0 V:

No further action required.

• If <= 11.99 V:

Figure 6

Before customer handover, Step \Rightarrow 6 - :**Documentation and replace battery** - must be carried out.

Figure 7

1.5 Document values, see \Rightarrow 20 ().

2 Vehicle is delivered to the Porsche Centre.

Figure 8

⇒ Further use as "direct" vehicle (vehicle is handed over to customer within five days,):

Direct:

2706 ENU **67/12**

2.1 Before sales check or pre-owned vehicle check ⇒ Connect recommended charger, see Step ⇒ , (⇒ Figure 9).




Figure 9

Figure 10

2.2 Perform sales check with charger connected ().

Figure 11

- 2.3 Park the vehicle in the warehouse ().
- 2.4 Within 48 36 hours **before customer handover**, continue with Step \Rightarrow 6.

Showroom:

Wehicle is delivered to the Porsche Centre.

Figure 12

⇒ Further use as "**showroom**" vehicle ():

3.1 Before sales check or pre-owned vehicle check ⇒ Connect recommended charger, see Step ⇒ , (⇒ Figure 13).




Figure 13

Figure 14

3.2 Perform sales check with charger connected ().

Figure 15

- 3.3 Vehicle comes into the showroom ().
- 3.4 Charging the battery in the **showroom** ():

2

67/12 ENU 2706

 \Rightarrow **Permanent**: Use the **cigarette lighter** and a suitable charger (Charge-o-mat II, see \Rightarrow) to **permanently** charge the battery.

Figure 16

- \Rightarrow Interval: Charge the battery every day (>= 10 hours) using a suitable charger, see Step \Rightarrow .
- 3.5 Within 48 36 hours **before customer handover**, continue with Step \Rightarrow 6.

Stock: 4 Vehicle is delivered to the Porsche Centre.

Figure 17

- ⇒ Further use as "stock" vehicle ():
- 4.1 Before sales check or pre-owned vehicle check ⇒ Connect recommended charger, see Step ⇒ , (⇒ Figure 18).




Figure 18

Figure 19

- 4.2 Perform sales check with charger connected ().
- 4.3 Before the vehicle comes into the warehouse:

Charge the battery using a recommended charger, see Step \Rightarrow , ().

Figure 20

Observe the **specifications** with regard to **battery temperature** ($>= 10^{\circ}$ C) and charging time of **at least 10 hours**.

Figure 21

- 4.4 Vehicle comes into the warehouse ().
- 4.5 Charging the battery in the warehouse ():
 - \Rightarrow **Permanent**: Use the **cigarette lighter** and a suitable charger (Charge-o-mat II, see \Rightarrow) to **permanently** charge the battery.

Figure 22

 \Rightarrow **Interval**: Charge the battery **once a month** (>= 10 hours) using a suitable charger, see \Rightarrow .

4.6 Within 48 - 36 hours **before customer handover**, continue with Step \Rightarrow 6.

Stock and demonstration is delivered to the Porsche Centre.

Figure 23

⇒ Further use as "**stock demo**" vehicle (also used as demo/exhibition vehicle,):

5.1 Before sales check or pre-owned vehicle check ⇒ Connect recommended charger, see ⇒ , (⇒ Figure 24).




Figure 24

Figure 25

- 5.2 Perform sales check with charger connected ().
- 5.3 Before the vehicle comes into the warehouse:

Charge the battery using a recommended charger, see \Rightarrow , ().

Figure 26

Observe the **specifications** with regard to **battery temperature** ($>= 10^{\circ}$ C) and charging time of **at least 10 hours**.

Figure 27

- 5.4 Vehicle comes into the warehouse and is used as a demo/exhibition vehicle there ().
- 5.5 Charging the battery in the warehouse and when used as a demo/exhibition vehicle ():
 - \Rightarrow **Permanent**: Use the **cigarette lighter** and a suitable charger (Charge-o-mat II, see \Rightarrow) to **permanently** charge the battery.

Figure 28

 \Rightarrow Interval: Charge the battery once a week (>= 10 hours) using a suitable charger, see Step \Rightarrow .

67/12 ENU

2706

Before customer handover:

Complete the next steps:

- ⇒ at the earliest 48 hours before vehicle handover,
- \Rightarrow but **at the latest 36 hours before** vehicle handover to the customer (\Rightarrow *Figure 29*):




Figure 29

Replacing battery:



Information

The **AGM battery**:

- is installed as standard equipment in the vehicle and **must not be replaced by a conventional** "starter battery" and
- must not be opened.

If the battery needs to be replaced, the following data must be entered in the gateway control unit using PIWIS Tester III (under Maintenance/repairs - Change battery):

- · Serial number,
- · part number,
- manufacturer and
- · battery size.

The battery sensor:

- is connected between the battery negative terminal and ground cable,
- is an important part of the energy management system and
- is used to **measure battery variables** (battery current, battery voltage and negative terminal temperature) for **vehicle electrical system diagnosis**.
- 6 Was a problem with the battery discovered following delivery of the vehicle?
 - 6.1 **NO**

 \Rightarrow Continue with Step \Rightarrow 7, section "Charging the battery".

6.2 **YES**

- ⇒ Within 48 36 hours before customer handover:
- 6.2.1 Complete the necessary **documentation** (see section 'Measurements', Step \Rightarrow 20),
- 6.2.2 Create a vehicle analysis log (VAL) and attach it to the job,
- 6.2.3 **Replace the battery** (), see ⇒ *Workshop Manual '270655 Replacing the battery'* and

Figure 30

6.2.4 \Rightarrow Continue with Step \Rightarrow 8, section "New battery".

Charging the batt∉ry: Within 48 - 36 hours **before customer handover** (⇒ Figure 31, but only following vehicle preparation), **charge the battery**:




Figure 31

NOTICE

A battery charger for providing an external power supply or for jump-lead starting is connected directly to the battery in the vehicle.

- Risk of damage to the battery sensor.
- Battery sensor sends incorrect battery values to the vehicle electrical system.
- ⇒ Always connect a battery charger for providing an external power supply or for jump-lead starting to the defined connections in the engine compartment. ⇒ Workshop Manual '2X00IN Battery trickle charging'
 - 7.1 Charge the battery using a recommended charger, see \Rightarrow , ().

Figure 32

Observe the **specifications** with regard to **battery temperature** (>= 10° C) and charging time of **at least 10 hours**.

Figure 33

Service

67/12 ENU 2706

7.2 Leave the battery "inactive" for 120 minutes ():

The vehicle must not be moved and no loads must be switched on during this time.

Figure 34

- 7.3 Measure voltage using a suitable voltmeter (). Observe recommended devices, see \Rightarrow 10 and battery temperature (>= 10° C/50° F).
- 7.4 Evaluate measured voltage ():
 - If measured voltage: >= 12.8 V:

Continue with \Rightarrow 7.5.

• If measured voltage: <= 12.79 V:

Figure 35

Before customer handover, Step \Rightarrow 6.2 - section "**Replacing the battery**" - must be carried out.

Figure 36

7.5 Check, evaluate and document functional state of the battery (, ,):

 \Rightarrow See section "Measurements", \Rightarrow 20.

Figure 37

Figure 38

End of remedial action.

New battery

8 Procedure for "charging" the **new battery** ():

Figure 39

Within 48 - 36 hours **before customer handover** (but only following vehicle preparation), **charge the battery**:

8.1 Charge the battery using a recommended charger, see \Rightarrow , ().

Figure 40

Observe the **specifications** with regard to **battery temperature** ($>= 10^{\circ}$ C) and charging time of **at least 10 hours**.

Figure 41

8.2 Leave the battery "inactive" for 120 minutes ():

The vehicle must not be moved and no loads must be switched on during this time.

Figure 42

- 8.3 Check, evaluate and document functional state of the battery (, ,): \Rightarrow See section "Measurements", \Rightarrow 20.
 - Figure 43

Figure 44

End of remedial action.

Recommended deviceRecommended measuring devices (battery testers, see also "Workshop Equipment Manual" -PIWIS information system):

- WE1019 Digital Multimeter Bosch MMD 302
- WE1253 Battery Tester BAT121 or
- WE1327 Battery Tester Midtronics inSPECT45.
- 11 Recommended **chargers** (see also "Workshop Equipment Manual" PIWIS information system):
 - WE1017 Battery Charging Computer DPBL 425B-14
 - WE1183 Battery Charger HESO Ladematic Combi III
 - WE1259 Bosch Battery Charger BML 2410/2415
 - WE1260 Bosch Battery Rapid-Start Charger BSL 2470
 - WE1315 Battery Charger ACCTIVA Professional 30A
 - WE1316 Battery Charger ACCTIVA Professional Flash 70A
 - WE1318 Battery Charger MultiCharger 750
 - WE1319 Battery Charging Computer DBL800-14
 - WE1353 Battery Charger HFL 65
 - WE1391 Deutronic Battery Charging Computer DBL1600-14
 - WE1392 Deutronic Battery Charging Computer DBL1200-14
 - WE1393 Deutronic Battery Charging Computer DBL800-14
 - WE1412 HFL 40 IUoU High-Frequency Battery Charger 6 + 12 + 24 volts
- 12 **Permanent trickle charging** (see Porsche Tequipment Accessories and Maintenance):
 - $955.044.900.56 \Rightarrow \text{Charge-o-mat II}$
 - $955.044.900.55 \Rightarrow \text{Charge-o-mat II (GB version)}$
 - $955.044.900.54 \Rightarrow$ Charge-o-mat II (USA version, 110 V)
 - **Adapter** (required for vehicles without cigarette lighter): 000.043.202.55 ⇒ Adapter (for Charge-o-matt II and vehicles without cigarette lighter)

Measurements: For taking measurements on the battery and for documentation purposes, use the existing Checklist (PIWIS information system, "Standard forms" menu: AGM Battery Checklist and measurement sheet...).



Information

When working on the vehicle:

- using the PIWIS Tester or
- for work that takes longer than 15 minutes,
- a charger must be connected in order to trickle-charge the battery.

Service

67/12 ENU 2706

2

- 20 The **Checklist and relevant procedure are described** below (Please **disregard** steps relating to a customer complaint):
 - 20.1 Step 1. (Checklist) **General data** relating to the vehicle and battery (\Rightarrow *Figure 45*):



Figure 45

- \Rightarrow The specifications on the battery (in the vehicle) may differ from the specifications shown in Figure 1
- ⇒ Illustration (⇒ Figure 45) serves only as an example.
- Battery type: rating in Ah (⇒ Figure 45 -item A-),
- Date of manufacture of the battery (stamped on negative terminal): ⇒ Figure 45 -item
 B-),
- Battery I-no. (for 2D code: ⇒ Figure 45 -item C-),
- Item number (⇒ Figure 45 -item D-) and
- Battery manufacturer (⇒ Figure 45 -item E-),
- Safety instructions and warnings for handling the battery (⇒ Figure 45 -item F-).
- 20.2 Step 2. (Checklist) Visual inspection of the battery:
 - Check for damage to the housing and
 - corroded and/or loose terminals.
- 20.3 Step 3. (Checklist) Check the battery using a **battery tester**, see section 'Measuring devices' ⇒ 10:
 - ⇒ Battery charge state before and after charging.

- Step 4. (Checklist) **Charge** the **battery** using a suitable charger (see section \Rightarrow , but with a current rating of at least 40 Ah \Rightarrow Observe minimum charging time (>= 10 hours) and read operating instructions for the charger.
- 20.5 Step 5. (Checklist) Measure the battery **open-circuit voltage** using a voltmeter or voltage tester.

Steps 6. to 8. (in Checklist) are not relevant.

- 21 As an **additional step**, Step 9. (Checklist) **Read out values from PIWIS Tester II** can be carried out:
 - 21.1 Connect the PIWIS Tester to the vehicle.
 - 21.2 Switch on ignition.
 - 21.3 Select the relevant vehicle in the "Diagnostics" menu.
 - 21.4 Select the 'Gateway' control unit in the "Control unit overview" menu and switch to the "Actual values/input signals" menu.
 - 21.5 Answer •YES" in response to the VAL (Vehicle Analysis Log) prompt.
 - 21.6 Read the campaign information instructions and confirm by pressing •F12".
 - 21.7 In the 'Actual values/input signals' overview, select "Battery" and "Battery charge state history" and press F12" to confirm.
 - 21.8 In the 'Actual values' overview, **select the following actual values**:

Pottory ogoing	charge-related %				
Battery ageing	performance-related %				
Battery internal resistance	Actual mOhm				
Battery charge state	%				
Open-circuit voltage	V				
Pattery temperature	(Acid)				
Battery temperature	(Terminal)				
Closed-circuit current	Below limit value (Duration) min.				
Closed-Circuit current	Limit value exceeded (Duration) min.				
	Battery charge state 0 25 %				
Battery charge state history	Battery charge state 26 50 %				
Batter y Charge State History	Battery charge state 51 75 %				
	Battery charge state 76 100 %				

21.9 Press • F12" to confirm your selection.

Service

67/12 ENU 2706

2

- 21.10 Read off actual values and enter them in the Checklist.
- 21.11 Press F11" to exit the display.
- 21.12 Press •F11" to go back.
- 22 **If, after completing the documentation, the battery** (Step \Rightarrow 6.2) **must be replaced**, go back to Step \Rightarrow 6.2.2.

End of remedial action.

References:

⇒ Technical Information '2706IN Important information for extending (AGM) battery life and battery performance (60/12)'

Important Notice: Technical Bulletins issued by Porsche Cars North America, Inc. are intended only for use by professional automotive technicians who have attended Porsche service training courses. They are written to inform those technicians of conditions that may occur on some Porsche vehicles, or to provide information that could assist in the proper servicing of a vehicle. Porsche special tools may be necessary in order to perform certain operations identified in these bulletins. Use of tools and procedures other than those Porsche recommends in these bulletins may be detrimental to the safe operation of your vehicle, and may endanger the people working on it. Properly trained Porsche technicians have the equipment, tools, safety instructions, and know-how to do the job properly and safely. If a particular condition is described, do not assume that the bulletin applies to your vehicle, or that your vehicle will have that condition. See your authorized Porsche Dealer for the latest information about whether a particular technical bulletin applies to your vehicle. Part numbers listed in these bulletins are for reference only. Always check with your authorized Porsche dealer to verify the current and correct part numbers. The work procedures updated electronically in the Porsche PIWIS diagnostic and testing device take precedence and, in the event of a discrepancy, the work procedures in the PIWIS

Tester are the ones that must be followed.

Dealership	Service Manager	 Shop Foreman	 Service Technician	 	
Distribution					
Routing	Asst. Manager	 Warranty Admin.	 Service Technician	 	

Dr. Ing. h.c. F. Porsche AG is the owner of numerous trademarks, both registered and unregistered, including without limitation the Porsche Crest®, Porsche®, Boxster®, Carrera®, Cayenne®, Cayman®, Macan®, Panamera®, Speedster®, Spyder®, 918 Spyder®, Tiptronic®, VarioCam®, PCM®, PDM®, 911®, RS®, 4S®, FOUR, UNCOMPROMISED®, and the model numbers and the distinctive shapes of the Porsche automobiles such as, the federally registered 911 and Boxster automobiles. The third party trademarks contained herein are the properties of their respective owners. Porsche Cars North America, Inc. believes the specifications to be correct at the time of printing. Specifications, performance standards, standard equipment, options, and other elements shown are subject to change without notice. Some options may be unavailable when a car is built. Some vehicles may be shown with non-U.S. equipment. The information contained herein is for internal authorized Porsche dealer use only and cannot be copied or distributed. Porsche recommends seat belt usage and observance of traffic laws at all times.