

Tech Tips

TT 00-14-03

Date: November 27, 2014

2000-2015 All Models (except Routan)-SVM Update Instructions

When performing SVM updates, the scan tool should be hardwired to the vehicle and the Bluetooth physically turned off. A hard wired internet connection is also recommended.

SVM Update Instruction

- Connect the tester to the on-line network using an Ethernet cable.
- Connect the VAS 5054A transmitter head to the VAS tester using the USB cable.
- Disable Bluetooth by physically turning the switch to the OFF position (Figures 1, 2 or 3).



Figure 1



Figure 2

Service Information



Figure 3



Note:

If the Bluetooth wireless VAS 5054A transmitter head is used in conjunction with a VAS tester, the transmitter head **MUST BE** connected with a USB cable to the tester.

The Bluetooth function of the scan tool **MUST BE PHYSICALLY SWITCHED OFF** prior to performing this update.