## 2016 Volkswagen *Jetta Sedan* Maintenance Schedule For USA 2.0L MPI Engine



| Miles   | 10K | 20K | 30K | 40K | 50K | 60K | 70K | 80K | 90K | 100K | 110K | 120K |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|
| Air filter element and snow filter: Replace and clean housing (Every 6 years regardless of mileage)   |     |     |     |     |     | 6   |     |     |     |      |      | 6    |
| Battery: Check  |     | Х   |     | Х   |     | Х   |     | Х   |     | Х    |      | Х    |
| Body: Visual inspection for corrosion   |     |     |     | X   |     |     |     | X   |     |      |      | X    |
| Brake pads: Check thickness and brake disc condition. Look for contact pattern and corrosion of brake discs (front and rear)  | x   |     | x   |     | x   |     | х   |     | x   |      | x    |      |
| Brakes: Inspect brake system and shock absorber for leaks and damage,<br>check thickness of brake pads, brake disc condition front and rear. Look for<br>contact pattern and corrosion of brake discs, and check brake fluid level<br>subject to abrasion |     | x   |     | x   |     | x   |     | x   |     | x    |      | x    |
| Brake fluid and clutch unit: Change fluid (Every 3 years regardless of mileage and every 2 years after)   |     |     | 3   |     | 3   |     | 3   |     | 3   |      | 3    |      |
| Coolant level and frost protection: Check   |     |     |     | X   |     |     |     | X   |     |      |      | X    |
| CV joints: Check for leaks and damage   |     |     |     | X   |     |     |     | Х   |     |      |      | Х    |
| Dust and pollen filter: Replace<br>(Every 2 years or 40,000 miles)  |     |     |     | 1   |     |     |     | 1   |     |      |      | 1    |
| Engine: Change oil and replace oil filter   | X   | Х   | X   | Х   | Х   | Х   | Х   | X   | Х   | Х    | X    | X    |
| Engine and engine compartment components: Check (from above) for leaks and damage   |     |     |     | x   |     |     |     | x   |     |      |      | x    |
| Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots   |     |     |     | x   |     |     |     | x   |     |      |      | x    |
| Exhaust system: Check for leaks, damage and secure fittings   |     |     |     | X   |     |     |     | X   |     |      |      | X    |
| Headlights: Check adjustment  |     |     |     | X   |     |     |     | X   |     |      |      | Х    |
| Interior lighting and glove box lights, cigarette lighter / power outlets, horn, and all warning lamps: Check   |     |     |     | x   |     |     |     | x   |     |      |      | x    |
| Lighting: Front and rear lights, luggage compartment lighting, turn signals, hazard warning lights: Check   |     |     |     | х   |     |     |     | x   |     |      |      | x    |
| Power steering: Check oil level   |     |     |     | Х   |     |     |     | Х   |     |      |      | Х    |
| Ribbed belt: Check condition (if applicable)  |     |     |     | Х   |     |     |     | Х   |     |      |      | X    |
| Service interval display: Reset   | Х   | Х   | Х   | Х   | Х   | Х   | Х   | Х   | Х   | Х    | Х    | Х    |

## 2016 Volkswagen *Jetta Sedan* Maintenance Schedule For USA 2.0L MPI Engine



| Miles   | 10K | 20K | 30K | 40K | 50K | 60K | 70K | 80K | 90K | 100K | 110K | 120 |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|------|-----|
|   | 1   |     |     |     |     |     |     |     |     |      |      |     |
| Spark plugs: Replace  |     |     |     | 5   |     |     |     | 5   |     |      |      | 5   |
| Sunroof and panoramic sunroof: Check, clean, and lubricate (if applicable)  |     |     |     | х   |     |     |     | х   |     |      |      | x   |
| Sunroof: Open sunroof and check front water drains and clean if necessary (if applicable)   |     |     |     | х   |     |     |     | x   |     |      |      | X   |
| Test drive: Check braking, kickdown, steering, electrical, heating and ventilation systems, air conditioning, handling, and parking brake   |     |     |     | х   |     |     |     | х   |     |      |      | Х   |
| Tie rod ends: Check for excessive play and looseness, check boots   |     |     |     | Х   |     |     |     | Х   |     |      |      | X   |
| Timing Belt: Check and replace if necessary <b>(2.0L MPI only)</b> If replaced at 60,000 miles, check every 60,000 miles after. If not replaced at 60,000 miles, check every 20,000 miles until replaced, then every 60,000 miles |     |     |     |     |     | x   |     | x   |     | x    |      | x   |
| Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare)   |     | x   |     | x   |     | х   |     | x   |     | x    |      | X   |
| Tire mobility kit: Check and observe expiration date on the tire filler bottle (Every 2 years regardless of mileage)  |     | 2   |     | 2   |     | 2   |     | 2   |     | 2    |      | 2   |
| Tire mobility kit: Replace tire filler bottle<br><b>(Every 4 years regardless of mileage)</b>   |     |     |     | 4   |     |     |     | 4   |     |      |      | 4   |
| Transmission: Automatic (non DSG): Change fluid   |     |     |     |     |     |     |     | Х   |     |      |      |     |
| Underbody sealant: Inspect for damage   |     |     |     | Х   |     |     |     | Х   |     |      |      | X   |
| Windshield washers, headlight cleaning system, and wiper blades: Check for damage and function, Check fluid level and add if necessary  | х   | x   | x   | x   | х   | х   | х   | х   | х   | x    | x    | x   |

1. Every 2 years or 40,000 miles: Dust and pollen filter: Replace (if applicable)

2. Every 2 years, regardless of mileage: Tire filler bottle in the tire mobility kit: Check (observe expiration date) (if applicable)

3. At the 3 year mark, then every 2 years regardless of miles driven: Brake fluid and clutch unit: Replace fluid

4. Every 4 years, regardless of mileage: Tire filler bottle in the tire mobility set: Replace (Observe expiration date)

5. Every 4 years regardless of mileage: Replace spark plugs

6. Every 6 years regardless of mileage: Air filter element and snow filter: Replace element and clean screen and housing (if applicable)

| 2016 Volkswagen <i>Jetta Sedan</i> Maintenance Schedule For USA<br>2.0L MPI Engine  |                   |                  |                 |          |                                 |                     |                   |                   |                    |          |               |      |  |  |
|---|-------------------|------------------|-----------------|----------|---------------------------------|---------------------|-------------------|-------------------|--------------------|----------|---------------|------|--|--|
| Miles   | 10K               | 20K              | 30K             | 40K      | 50K                             | 60K                 | 70K               | 80K               | 90K                | 100K     | 110K          | 120K |  |  |
| © 2015 Volkswagen Group of America, Inc.  |                   |                  |                 |          |                                 |                     |                   |                   |                    |          |               |      |  |  |
| All rights reserved. Information contained in this document is bas<br>to the copyright and other intellectual property rights of Volkswag<br>rights are reserved to make changes at any time without notice.<br>No part of this document may be reproduced, stored in a retrieval<br>mechanical, photocopying, recording, or otherwise, nor may these<br>expressed written permission of the publisher.<br><b>Posted: August 2015</b> | ien Gr<br>I syste | oup of<br>em, or | Ameri<br>transm | ica, Ind | c., its a<br>n any <sup>-</sup> | affiliate<br>form o | ed com<br>r by ar | npanie:<br>ny mea | s and i<br>ans, el | its lice | nsors.<br>ic, | •    |  |  |