

Subject

**Navigation/Multi Info Display Day Mode Operation**

Market

USA

Service Category

Audio/Visual/Telematics

Section

Navigation/Multi Info Display

Applicability

All Vehicles with Navigation

**APPLICABLE VEHICLES**

2010-2014	IS250C	2001-2003	ES300
2002-2010	SC430	2008-2014	LS600H
2001-2006	GS300	2006-2014	IS250
2006-2008	RX400H	2001-2005	IS300
2008-2011	GS460	2007-2011, 2013-2014	GS450H
2001-2003	RX300	2010-2012	HS250H
2013-2014	ES300H	2004-2006	ES330
2007-2014	ES350	2007-2014	LS460
2003-2009	GX470	2010-2014	GX460
2001-2007	LX470	2010-2014	RX450H
2007-2011, 2013-2014	GS350	2011-2014	CT200H
2006-2014	IS350	2007-2014	RX350
2004-2006	RX330	2001-2007	GS430
2010-2014	IS350C	2001-2006	LS430
2008-2014	IS F	2008-2011, 2013	LX570

**CONDITION**

The customer is having difficulty changing the multi-display screen from Day Mode.

If the multi-display screen is set to Day Mode when the headlights are on, the setting will be memorized when the engine is turned off. When the customer is driving the vehicle at night, and the instrument panel light control knob is turned fully to the right, the Day Mode button will not appear on the multi-display screen.

**RECOMMENDATIONS**

Follow the procedure below to turn the Day Mode off.

1. Confirm that the instrument panel control knob is in the middle position, the headlights are on, and the solar sensor is covered if it is daytime.
2. Push Display button on the multi-display assembly.
3. Touch the Day Mode button on the screen.

**LINK REFERENCES**

Subject

# Navigation/Multi Info Display Day Mode Operation

Market

USA

Applicability

All Vehicles with Navigation

Click here to enter text.

r