

Subject

P3190/P3191/P3193/P0A0F Engine No Start/Poor Engine Power After Inverter Service or Replacement

Market

USA

Service Category

Engine/Hybrid System

Section

Engine Control

Applicability

Highlander HV

APPLICABLE VEHICLES

2006-2012

Highlander HV

CONDITION

Engine No Start and/or Poor Engine Power DTCs set immediately after performing service on the Inverter such as SSC D0M for IPM replacement or Inverter Assembly installation.

RECOMMENDATIONS

All intake system components such as air filter, air cleaner housing, resonators, air induction hoses and ducts **MUST** be installed before attempting Ready On or engine performance DTCs may occur.

LINK REFERENCES

This Tech Tip does not contain any link references