



Remove Top black
Connector to
disconnect CAN from
the headunit.