



Bulletin No.: PIT5719A

Published date: N/A

# Preliminary Information

## PIT5719A Diagnostic Tip - Brake Booster Pump Motor Runs at All Times Even After Ignition Turned Off

### Models

Brand:	Model:	Model Years:	VIN:		Engine:	Transmissions:
			from	to		
Chevrolet	Silverado 4500HD, 5500HD, 6500HD	2019	SOP	Built Before 8/1/2019	All	All

Involved Region or Country	North America
Condition / Concern	Some customers may comment that the brake booster pump motor runs at all times even after the ignition is turned off. The dealer may find DTC C0021 set in EBCM.

### Recommendations / Instructions:

Disconnect the B356 brake pipe pressure switch to verify brake booster stops running. If so, replace the B356 Brake Pipe Pressure Switch and evaluate for concern.

### Version History

Version	<b>1</b>
Modified	11/14/2019 - Created on 4/16/2020 - Updated to add build date breakpoint



GENERAL MOTORS

© 2020 General Motors. All Rights Reserved.