| 2015 Volkswagen <i>GTI</i> Maintenance Schedule For USA 2.0TFSI Engine | | | | | | | | | | | | |
|---|------|------|------|------|------|------|------|------|------|------|------|------|
| Miles | 10K | 20K | 30K | 40K | 50K | 60K | 70K | 80K | 90K | 100K | 110K | 120K |
| | | | | | | | | | | • | | |
| Airbag system: Perform visual inspection (Every 1 year regardless of mileage) | 1, * | 1, * | 1, * | 1, * | 1, * | 1, * | 1, * | 1, * | 1, * | 1, * | 1, * | 1, * |
| Air filter element and snow filter: Replace and clean housing (Every 6 years regardless of mileage) | | | | | | 8, * | | | | | | 8, * |
| Battery: Check | | Х | | Х | | Х | | Х | | Х | | X |
| Body: Visual inspection for corrosion | | | | X | | | | X | | | | X |
| Brake pads: Check thickness and brake disc condition. Look for contact pattern and corrosion of brake discs (front and rear) | х | | x | | x | | x | | x | | x | |
| Brakes: Inspect brake system and shock absorber for leaks and damage, check thickness of brake pads, brake disc condition front and rear. Look for contact pattern and corrosion of brake discs, and check brake fluid level subject to abrasion | | x | | x | | x | | x | | x | | x |
| Brake fluid and clutch unit: Change fluid (Every 3 years regardless of mileage and every 2 years after) | | | 4, * | | 4, * | | 4, * | | 4, * | | 4, * | |
| Coolant level and frost protection: Check | | | | X | | | | Х | | | | X |
| CV joints: Check for leaks and damage | | | | X | | | | X | | | | X |
| Door checks and mounting pins: Lubricate | | | | X | | | | X | | | | X |
| Dust and pollen filter: Replace (Every 2 years regardless of mileage) | | 2, * | | 2, * | | 2, * | | 2, * | | 2, * | | 2, * |
| Engine: Change oil and replace oil filter | Х | Х | Х | Х | Х | X | Х | Х | X | Х | Х | Х |
| Engine and engine compartment components: Check (from above) for leaks and damage | | | | x | | | | x | | | | x |
| Engine and engine compartment components: Check (from below) for leaks and damage, check transmission, final drive, and drive shaft boots | | | | x | | | | x | | | | x |
| Exhaust system: Check for leaks, damage and secure fittings | | | | Х | | | | Х | | | | Х |
| Front axle differential lock (if equipped): Change fluid (Every 3 years) | | | 5, * | | | 5, * | | | 5, * | | | 5, * |
| Headlights: Check adjustment | | | | X | | | | X | | | | X |
| Interior lighting and glove box lights, cigarette lighter / power outlets, horn, and all warning lamps: Check | | | | x | | | | x | | | | x |

| 2015 Volkswagen <i>GTI</i> Maintenance Schedule For USA 2.0TFSI Engine | | | | | | | | | | | | |
|---|-----|------|-----|------|-----|------|-----|------|-----|------|------|------|
| Miles | 10K | 20K | 30K | 40K | 50K | 60K | 70K | 80K | 90K | 100K | 110K | 120K |
| | | | | | 1 | 1 | | | | • | | |
| Lighting: Front and rear lights, luggage compartment lighting, turn signals, hazard warning lights: Check | | | | x | | | | x | | | | x |
| Power steering: Check oil level | | | | X | | | | Х | | | | X |
| Rear window: Check cleaning nozzle functionality (if applicable) | X | Х | X | Х | Х | Х | Х | Х | X | Х | Х | Х |
| Ribbed belt: Check condition (if applicable) | | | | Х | | | | Х | | | | X |
| Service interval display: Reset | X | Х | X | Х | Х | Х | Х | Х | X | Х | Х | X |
| Service sticker: Enter the date of the next service on the service sticker and apply to the driver's side door pillar | X | х | x | x | X | X | X | x | x | x | х | x |
| Spark plugs: Replace | | | | | | 7, * | | | | | | 7, * |
| Sunroof and panoramic sunroof: Check, clean, and lubricate (if applicable) | | | | X | | | | Х | | | | X |
| Sunroof: Open sunroof and check front water drains and clean if necessary (if applicable) | | | | x | | | | x | | | | x |
| Test drive: Check braking, kickdown, steering, electrical, heating and ventilation systems, air conditioning, handling, and parking brake | | | | x | | | | x | | | | x |
| Tie rod ends: Check for excessive play and looseness, check boots | | | | X | | | | X | | | | Х |
| Tires: Check tread depth, condition, wear pattern and pressure of all tires (including spare) | | x | | x | | x | | x | | x | | x |
| Tires: Rotate front to rear | X | Х | Х | X | Х | Х | Х | X | X | X | Х | X |
| Tire mobility kit: Check and observe expiration date on the tire filler bottle (Every 2 years regardless of mileage) | | 3, * | | 3, * | | 3, * | | 3, * | | 3, * | | 3, * |
| Tire mobility kit: Replace tire filler bottle (Every 4 years regardless of mileage) | | | | 6, * | | | | 6, * | | | | 6, * |
| Transmission: DSG (non Automatic): Change fluid and filter (if applicable) | | | | x | | | | x | | | | x |
| Underbody sealant: Inspect for damage | | | | x | | | | x | | | | x |
| Windshield washers, headlight cleaning system, and wiper blades: Check for damage and function, Check fluid level and add if necessary | x | x | x | x | x | x | x | x | x | x | x | x |

| 2015 Volkswagen <i>GTI</i> Maintenance Schedule For USA 2.0TFSI Engine | | | | | | | | | | | | Ø |
|---|-----------------|--------------------|------------------|---------------------|----------------------|--------------|----------------|-----------------|--------------------|--------|---------|-----|
| Miles | 10K | 20K | 30K | 40K | 50K | 60K | 70K | 80K | 90K | 100K | 110K | 120 |
| * Carefree Maintenance Program - Time dependent items will be inclu | uded in | n sched | uled m | nainte | nance | interv | als if a | applica | able | | | |
| 1. Every 1 year, regardless of mileage: Perform visual check of airbag sys | | | | | | | | | | | | |
| 2. Every 2 years, regardless of mileage: Dust and pollen filter: Replace (if | i applio | cable) | | | | | | | | | | |
| 3. Every 2 years, regardless of mileage: Tire filler bottle in the tire mobility | v kit: Cł | neck (ol | oserve | expira | ation o | date) (| if appl | icable |) | | | |
| 4. Every 3 years, regardless of mileage and every 2 years after: Brake flu | id and | clutch u | nit: Re | place | fluid | | | | | | | |
| 5. Every 3 years, Front axle differential lock (if equipped): Change fluid | | | | | | | | | | | | |
| 6. Every 4 years, regardless of mileage: Tire filler bottle in the tire mobility | v set: R | eplace | (Obse | rve ex | piratio | on dat | e) | | | | | |
| 7. Every 6 years regardless of mileage: Replace spark plugs | | | | | | | | | | | | |
| 8. Every 6 years regardless of mileage: Air filter element and snow filter: I | Replac | e eleme | nt and | clean | screer | n and h | nousiną | g (if ap | plicat | ole) | | |
| © 2020 Volkswagen Group of America, Inc. | | | | | | | | | | | | |
| All rights reserved. Information contained in this document is based to the copyright and other intellectual property rights of Volkswagen rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval sy mechanical, photocopying, recording, or otherwise, nor may these n expressed written permission of the publisher. Posted: October 2020 | Group /stem, | o of Am or tran | erica, smitte | Inc., it d in ai | ts affili ny forr | ated on or b | compa y any | anies a mean | and its s, eleo | licens | sors. A | |