




Fuel Level Gauge Reading Incorrect In The Instrument Cluster (MID 140)



> Internal Content

If the Volvo Chassis - Cluster fuel level gauge reads incorrect—usually after the fuel level sender or tank(s) have been replaced—confirm that the "Total Useable Gallons/Liters" value shown on each tank is added together to get the "Total Useable Gallons" value entered for parameter 9A found in the Cluster (MID140).



Tags

[fuel level gauge](#) [k24946360](#)

[mid 140 instrument cluster](#) [volvo](#)

Live UI

Related links and attachments

No links or attachments available



Feedback

[Give feedback](#)

to help improve the content of this article