



Preliminary Information

PIT5960 Rear Map/Reading Lamps Stay On When Attempting To Start The Vehicle

Models

Brand:	Model:	Model Years:	VIN:		Engine:	Transmissions:
			from	to		
Buick	Envision	2021 - 2022	All	All	All	All

Involved Region or Country	North America
Condition	Some customers may comment that the rear map/reading lamps come on when starting the vehicle. If the map/reading lamp button is pressed the lamps will turn off.
Cause	Weak battery could cause the overhead console to command on the map/reading lamps while cranking.

Correction:

Test the battery using GM approved methods. If test fails, replace the battery. If it passes follow SI diagnostics.

Warranty Information

For vehicles repaired under the Bumper-to-Bumper coverage (Canada Base Warranty coverage), use the following labor operation. Reference the Applicable Warranties section of Investigate Vehicle History (IVH) for coverage information.

Labor Operation	Description	Labor Time
4041510	Battery Replacement	Use Published Labor Operation Time
*This is a unique Labor Operation for Bulletin use only.		

Version History

Version	1
Modified	11/29/2022- Created on



GENERAL MOTORS

© 2022 General Motors. All Rights Reserved.