



57 Ignition does not automatically turn on when entering the vehicle

57 22 99 2068823/1 December 7, 2022.

Model(s)	Year	VIN Range	Vehicle-Specific Equipment
e-tron GT, and RS e-tron GT	2022 – 2023	All	Not Applicable

Condition

Customer states:

- The ignition occasionally does not automatically switch on when entering the vehicle.

Workshop findings:

- No relevant DTCs are stored.

Technical Background

The vehicle must first be unlocked before it will automatically turn on the ignition.

Production Solution

Not applicable.

Service

Explain the steps needed for the ignition to automatically turn on.



The vehicle must already be in a locked state and asleep.

1. Unlock the vehicle.
2. Open the driver's door.
3. Get into the vehicle with a valid key.
4. Close the driver's door.
5. The ignition switches on automatically. The green "Ready" is displayed in the instrument cluster.

Warranty



This TSB is informational only and not applicable to any Audi warranty.

Additional Information

All part and service references provided in this TSB (**2068823**) are subject to change and/or removal. Always check with your Parts Department and/or ETKA for the latest information and parts bulletins. Please check the Repair Manual for fasteners, bolts, nuts, and screws that require replacement during the repair.

©2022 Audi of America, Inc. All rights reserved. The information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Audi of America, Inc., its affiliated companies, and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.