

Knocking Noises From Area Of Steering Gear

Topic number	LI46.35-P-075933
Version	1
Function group	46.35 - Electrical steering
Date	2/22/23
Validity	Model series 167
Reason for change	

Complaint

Knocking noises from area of steering gear, particularly when decelerating or accelerating.

Cause

-

Remedy

Please create a TIPS case with informative videos and send this to the responsible MPC.

Symptoms
Chassis/suspension > Steering system > Noises > Dragging/squealing
Chassis/suspension > Steering system > Noises > Cracking
Chassis/suspension > Steering system > Noises > Chattering/knocking
Chassis/suspension > Steering system > Noises > Humming/vibrations
Chassis/suspension > Steering system > Noises > Clattering

Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note