



Automated Manual Transmission (AMT) Transmission Kickdown Mode



Internal Content

TS request Matthew Beauchamp

85164482	P1APZ=2	TS: Kick-down only in economy
85164483	P1APZ=3	TS: Kick-down only in standard/balanced mode
85164484	P1APZ=0	TS: Disable Kick-down

Accessory kits have been developed to change the settings of P1APZ (Transmission Kickdown mode)

Accessory Kit P/N	Parameter Value	Description
85142840	P1APZ=1	TS: Kick-down always available

1. In Premium Tech Tool, run Operation [1700-22-03-06 Accessory Kit](#), located under the Program tab.
2. In the Accessory Kit number entry field, enter the applicable accessory kit p/n.
3. Click **Program**.
4. Allow the operation to complete and click **Exit**.

 Tags [mack](#) [kickdown](#) [volvo](#)

Categories 

Make and Model > Mack > CXU/CHU/PI - Pinnacle

Make and Model > Mack > LEU - TerraPro Low Entry

Make and Model > Mack > LR

Make and Model > Mack > TD - Titan

Make and Model > Volvo > VNL

 Live UI and Model > Volvo > VNR

Make and Model > Volvo > VNM

Make and Model > Volvo > VNX

Make and Model > Volvo > VAH

Make and Model > Volvo > VHD

Make and Model > Volvo > VT

Make and Model > Mack > MRU/TE - TerraPro

Vehicle System > Control Systems

Make and Model > Mack > AN - Anthem

Make and Model > Mack > GU/GR - Granite

Related links and attachments

No links or attachments available



Feedback

[Give feedback](#) to help improve the content of this article

Programming Steps

- Retrieving software part numbers
- Reading out transferable parameters from affected Electronic Control Units
- Downloading software from central systems
- Programming Electronic Control Units
- Programming parameters
- Finalizing programming

1700-22-03-06 Accessory Kit

Enter an accessory kit number and click Program to apply the kit

Kit number:

