

LEVELING

Purpose

This document is an introduction to the basic functions and operation of the Titan Leveling Systems™ Motorized Leveling System. For more system information, components, and vehicle-specific system manuals, navigate to <https://support.lci1.com/lippert-motorized-titan-leveling-system>

PreparationAuto Level

The leveling system shall only be operated under the following conditions:

1. The ignition is on.
2. The coach "parking brake" is engaged.
3. The coach transmission should be in the park position.
4. All people and pets are outside of the vehicle. **There should be no movement inside the coach.**
5. On the Controller (or Smart Device if connected via bluetooth) press "Auto Level" on the "Home Screen" (Fig. 1A).
6. After the "Level Success!" screen shows (Fig. 2), turn off the ignition.

Fig. 1





Fig. 2



LEVELING

Retracting the Jacks

1. Turn the ignition on.
2. There are two ways to retract the leveling jacks:
 - A. On the Controller (or Smart Device if connected via bluetooth) press "Retract Jacks" on the "Home Screen" (Fig. 1B).
 - B. Disengage the Parking Brake, and the Jacks will automatically retract.

Procedure

1. After scanning the QR code on the Titan Leveling Systems Touch Panel, select the appropriate link from the following options for the mobile device chosen to operate the system.
 - A. For Apple App Store: <https://apps.apple.com/us/app/lippert-basecamp-leveling/id1602715378>
 - B. For Google Play Store: <https://play.google.com/store/apps/details?id=com.lippert&pli=1>
2. Download and install the Lippert Titan Leveling Systems Leveling App (Fig. 3).

Fig. 3

