


### Multi-Model - Non-Reusable Part Service Caution

	Symbol	Description	Example
When removing parts from a vehicle, take caution of this symbol.	<b>R</b>	Replace Part	Bolt, O-ring, Gasket

Failing to replace the non-reusable part may cause a system failure.

Below is an example of a 2016-2017 Mazda2 intermediate shaft removal/installation:

Intermediate shaft bolts are NON-REUSABLE. If intermediate shaft (C) removal is necessary, discard bolt A and B. Replace them with a new ones. The bolts may come loose while driving if reused.



An editorial board comprised of MNAO service staff members generates, collects, and verifies information for this publication. © 2016 Mazda Motor of America, Inc.

To contribute repair tip ideas, send an e-mail to [mtips@mazdausa.com](mailto:mtips@mazdausa.com) or fax to (949) 442-6599. If we select your repair tip, you will receive 10,000 Reward Performance by Mazda (RPM) points for your efforts. All contributions become property of MNAO, which assumes permission to publish them without further consideration.