

Technical Service Bulletin

SUBJECT: TSB-17-54-001 No: PROCEDURE FOR ENGINE OVERHEATING January, 2017 DATE: MESSAGE IN COMBINATION METER -MODEL: 2014-17 Outlander SERVICE MANUAL REVISION CIRCULATE TO: [] GENERAL MANAGER [X] PARTS MANAGER [X] TECHNICIAN [X] SERVICE ADVISOR [X] SERVICE MANAGER [] WARRANTY PROCESSOR []SALES MANAGER

PURPOSE

This TSB updates the Chassis Electrical section of the affected Service Manuals to correct a reference in the Combination Meter Check Procedure chart.

AFFECTED VEHICLES

2014 – 2017 Outlander

AFFECTED SERVICE MANUALS

2014 — 2017 Outlander Service Manual, Group 54 — Chassis Electrical —> Combination Meter —> Check Procedure for Each Multi Information Display Screen <High Contrast Meter>



Please make the indicated changes to the 2014 - 2017 Outlander Service Manual, Group 54 - Chassis Electrical -> Combination Meter -> Check Procedure for Each Multi Information Display Screen <High Contrast Meter>.

NOTE: Refer to DTCs P0116, P0125, P0128, and P011B (2016MY) in Group 13A Diagnostic Trouble Code Chart.

Display content	Message	Factor	Action procedure
(!) AC809643	LOW TIRE PRESSURE	Displayed when the tire air pressure is an abnormality. (except spare tire)	If the warning screen is not displayed normally or erased, carry out the troubleshooting for the TPMS (Refer to GROUP 31, Diagnosis).
(!) AC809643	TPMS SERVICE REQUIRED	Displayed when the TPMS is an abnormality.	
AC809617	BRAKE SYSTEM SERVICE REQUIRED	Displayed when the brake fluid amount is insufficient or a malfunction occurs to the brake device.	If the warning screen is not displayed normally or if the screen continues to be displayed, check the brake fluid or brake device. Refer to GROUP 35A – Onvehicle Service.
(!) AC809617	RELEASE PARKING BRAKE	Displayed if vehicle is driven with the parking brake engaged.	If the warning screen is not displayed normally or if the screen continues to be displayed, check the parking brake. Refer to GROUP 36 – On-vehicle Service.
(ABS) AC809618	ABS SERVICE REQUIRED	Displayed when a malfunction occurs to the anti-lock braking system (ABS).	If the warning screen is not displayed normally or if the screen continues to be displayed, perform the troubleshooting for the ASC. Refer to GROUP 35C – Trouble Symptom Chart.
₹ AC809619	ENGINE OVERHEATING STOP SAFELY	Displayed when overheated. <pre></pre>	If the warning screen is not displayed normally or if the screen continues to be displayed, perform the troubleshooting for the engine. Refer to GROUP 13A Trouble Symptom Chart.
AC809620	TRANSMISSION OVERHEATING SLOW DOWN	Displayed when the transmission oil temperature becomes high.	If the warning screen is not displayed normally or if the screen continues to be displayed, check the CVT or A/T DTC. Refer to GROUP 23A – DTC Chart <cvt> or refer to GROUP 23C –</cvt>
AC809621	TRANSMISSION SERVICE REQUIRED	Displayed when there is a malfunction to the CVT or A/T.	DTC Chart .