

<small>Subject</small>	Techstream Health Check only shows "Yes" for a Telematics ECU (DCM) Calibration Update	<small>Market</small>	USA
<small>Service Category</small>	Audio/Visual/Telematics	<small>Section</small>	Cellular Communication
<small>Applicability</small>	All Lexus equipped with Safety Connect		

APPLICABLE VEHICLES

2015	RC F	2015	RC350
2015	NX300H	2010-2012	HS250H
2013-2015	ES300H	2010-2015	IS250C
2010-2015	ES350	2010-2015	LS600H
2012	LFA	2010-2015	LS460
2010-2015	GX460	2010-2015	RX450H
2010-2015	IS250	2011-2015	CT200H
2010-2011, 2013-2015	GS350	2010-2015	IS350
2010-2015	RX350	2015	NX200T
2010-2015	IS350C	2010-2011	GS460
2010-2011, 2013-2015	GS450H	2010-2014	IS F
2010-2011, 2013-2015	LX570		

CONDITION

Techstream Health Check Results screen shows "Yes" for a Telematics ECU (DCM) Calibration update regardless of whether a calibration update is available or not. The issue is related to the Techstream software and will be corrected in a future Techstream software release.

RECOMMENDATIONS

Search for the desired vehicle in the TIS Calibration Portlet (TIS/Diagnostics/Calibrations). If the calibration listed in the "New ECU CAL ID" column is newer than the calibration version shown on the Techstream Health Check Results, a calibration update for the Telematics ECU (DCM) is available. The update can be executed from the associated Technical Service Bulletin (TSB) listed in the Calibration Portlet. If there is no calibration listed in the "New ECU CAL ID" column, or if the version is the same or older than the calibration version listed in the Techstream Health Check Results, no Telematics ECU (DCM) update is available.

LINK REFERENCES

This Tech Tip does not contain any link references

