

WORK DESCRIPTION FOR FIELD MEASURE

Code: 18P5490405

Version: 2.0

Update software of AIR BODY CONTROL (ABC) control unit

Model 167 with code 490

i Code 490 corresponds to electrohydraulic suspension (E-suspension)

- i** • Ensure use of **XENTRY Diagnosis version BD/DVD (03/2019)** or higher.
- Before starting the work procedure, install all the **current versions of all add-ons** in **XENTRY Diagnosis**.
- Please make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
 - i** If two or more software updates or SCN codings are performed during one workshop visit, invoice operation items 02-4762 and 02-5058 **only once for each workshop order!**

Work procedure

1. Connect XENTRY Diagnosis.
2. Update software of N51/8 - **AIR BODY CONTROL (ABC)** control unit.
 - i** To do this, select menu item "Quick test view - N51/8 - AIR BODY CONTROL (ABC) - Adaptations - Control unit update - Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
3. Disconnect XENTRY Diagnosis.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9334	Update software of AIR BODY CONTROL (ABC) control unit (XENTRY Diagnosis connected)	0.1 h	54 904 05
02-4762*	Connect/disconnect vehicle diagnosis system (XENTRY Diagnosis)	0.1 h	54 904 05
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 904 05

* Invoice operation item only once for each workshop order!

Mercedes-Benz
Global Service & Parts