

WORK DESCRIPTION FOR FIELD MEASURE

Code: 19P5498401

Version: 2.0

Update sound system control unit software

Model 190 with code 810 or 811

- Code 810 corresponds to PREMIUM SOUND SYSTEM.
- Code 811 corresponds to HIGH END SOUND SYSTEM.

- i** • Ensure use of **XENTRY Diagnosis version BD/DVD (09/2019)** with add-on 13752 or higher.
- Before starting the work procedure, install all the **add-ons that are updated daily** in **XENTRY Diagnosis**.
- Please make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
 - i** If two or more software updates or SCN codings are performed during one workshop visit, the operation items 02-4762 and 02-5058 may be invoiced **only once for each workshop order!**

Work procedure

1. Connect XENTRY Diagnosis.
2. Update sound system control unit software.
 - i** To do this, select menu item "Quick test view – N40/7 sound system (SOUND) – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY Diagnosis.
3. Disconnect XENTRY Diagnosis.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9334	Update sound system control unit software (XENTRY Diagnosis connected)	0.1 h	54 984 01
02-4762*	Connect/disconnect diagnosis system (XENTRY Diagnosis)	0.1 h	54 984 01
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 984 01

* Operation item may be invoiced only once for each workshop order!

Mercedes-Benz
Global Service & Parts