Cabinet Mounting Screws Missed Wall Backers

Bulletin Type:	Standard Repair Procedure SRP		Publication Date:	February 2020
Bulletin #:	20-005		Makes:	Jayco Entegra
Job Code(s):	de(s): **		Models:	Redhawk SE Redhawk
Flat Rate(s):	**			Esteem Odyssey
** If affected unit has warranty remaining, submit claim following the normal process.			Model Year:	2020
Incident:		Medicine cabinet mounting screws missed horizontal wall backers.		
Affected Units:		Redhawk SE: L1GA, L1GJ Redhawk : L1XB, L1XJ Esteem: L3BD Odyssey: L3EB, L3ED, L3EJ, L3EK		
Parts Kit:		4 – Screw, RW QUAD 8 X 1.50 .67 DT 17 SB (0248555)		
Misc. Tools & Supplies:		Screw gun with #2 square drive bit		
Parts Return Information:		N/A		

REPAIR INSTRUCTIONS

FIG 1:

- Medicine cabinet was mounted 3" down from ceiling.
- Screws securing the medicine cabinet to the wall miss the horizontal wall backers when the cabinet is in this position.



FIG 2:

- There is one screw installed in the center of both shelf cleats (circled).
- Wall backers are 3 inches higher, and these screws miss those support backers.







FIG 3:

- Install two (2) screws in each shelf cleat, at the outer ends (4-locations circled).
- Insure the screws hit the vertical steel backers behind the wall on each side of the cabinet.

FIG 4:

• 4 screws must be within 1 inch of the vertical wood framework of the cabinet on each side of the cabinet. This should ensure they hit the vertical steel wall backers.



Jayco's sole obligation under our limited warranty is to repair or replace defective materials and/or workmanship deemed our responsibility as determined by Jayco in our sole discretion. Jayco reserves the right to use new and/or remanufactured parts or materials of similar quality to complete any work, and to make parts and/or design changes as appropriate without notice to anyone. Jayco designs and/or materials changes are done without obligation to incorporate such changes in previously manufactured product. Jayco makes every reasonable effort to ensure field remedies will not adversely affect performance and/or safety of the unit. This field remedy is not intended to extend to future performance of this RV, or any of its materials, components or parts beyond the standard warranty period. The RV owner's obligation to notify Jayco, or one of its independent, authorized dealers, of a claimed defect does not modify any obligation placed on the RV owner to contact Jayco directly when attempting to pursue remedies under state or federal law. Jan. 2019.

903 South Main Street • P.O. Box 460 • Middlebury, IN 46540