Service Alert

Mazda North American Operations Irvine, CA 92618-2922



Subject:

GEN 6 INFOTAINMENT CENTER DISPLAY REPAIR KIT (GHOST TOUCH, SPIDER CRACKING, SURFACE PEELING)

Service Alert No.: SA-041/22

Last Issued: 06/22/2022

BULLETIN NOTES

APPLICABLE MODEL(S)/VINS

2014-2016 Mazda3 2016-2021 Mazda6 2017-2020 CX-5

DESCRIPTION

Some customers may complain about infotainment center display:

Ghost Touch	(Touch screen operates by itself)
Surface Peeling	
Spider Cracks	87.9

Repair kits are available to replace just the screen. There is no need to replace the entire infotainment display unit.

Customers having this concern should have their vehicle repaired using the following repair procedure.

Page 1 of 23

Last Issued : 06/22/2022

REPAIR PROCEDURE

Service Alert No.: SA-041/22

Index


Model	Year	Symptom		
		Ghost Touch	Surface Peeling	Spider Cracking
Mazda3	2014-2016	Go to SSPB6	Go to Mazda3 Repair	Go to Mazda3 Repair
Mazda6	2016-2017 with VINS lower than JM1GL*****156205 produced on or before December 29, 2017)	Go to TSB 09-037/ 21	Go toTSB 09-037/21	Go to Mazda6 Repair
	2017-2022 with VINS higher than JM1GL*****156205 produced after December 29, 2017)	Go to Mazda6 Repair	Go to Mazda6 Repair	Go to Mazda6 Repair
CX-5	2017-2020 with VINs lower than JM3KF*****869655 produced before August 25, 2020)	Go to TSB 09-003/	Go to TSB 09-003/22	Go to CX-5 Repair

- 1. Verify the customer concern.
- 2. Disassemble the center display and replace the lens (inner part) with a newly established part according to the following steps:

NOTE: Wear the rubber gloves to protect the lens, cable and electronic circuit.

Repair parts set:

No.	Description	Qty.	Notes
(1)	Center Display Lens	1	Cushion materials for packa ging are used to protect the I ens surface when disassem bled.
(2)	Rubber gloves	1	Anti-static







Page 2 of 23

NOTE:

- Center display lens is packaged in bubble wrap and cushion material.
- Unwrap the package carefully so the cushion material can be used to protect the lens surface when disassembling the center display.
- · The center display lens is equipped with cables (FPC: Flexible Printed Circuit), so be careful when handling it.



(1) Bubble wrap



(2) Cushion material


CENTER DISPLAY DISASSEMBLY:

Remove the center display according to the instructions on MGSS:

- Mazda3 CENTER DISPLAY REMOVAL/INSTALLATION
- Mazda6 CENTER DISPLAY REMOVAL/INSTALLATION
- CX-5 CENTER DISPLAY REMOVAL/INSTALLATION

Mazda3 Repair

1. Remove the 4 screws (1), then remove the connectivity master unit (CMU) (2) from the center display (3).



2. Place the cushion sheet (1) that wrapped lens before, on a clean, flat surface.


Page 3 of 23

- 3. Put on the rubber gloves.
- 4. Place the center display (2) on the cushion sheet (1) with the display side facing downward.




5. Remove the 4 screws from the center display cover panels.






6. Remove the lower cover panel by pulling it up off the bracket, then lift off the back cover panel.



Page 4 of 23


Last Issued : 06/22/2022

7. Remove the 4 screws from the bracket.



8. Unlock the bracket with a flat head screw driver by carefully prying out and upward on the bracket.






CAUTION: DO NOT pry on the printed circuit board.

9. Remove the bracket.




Page 5 of 23

10. Unlock and disconnect the printed wiring harness




11. Remove the electric circuit board (1) from the display lens (2).



CAUTION: Be very careful handling the electric circuit board as it will be reused.


Page 6 of 23

12. Assemble the modified display lens with the removed electric circuit board.



NOTE 1:

- Peel off the protection film from the inside lens surface when replacing.
- Peel off the protection film on the outside lens surface after installing the center display to the vehicle.



NOTE 2: Solidly connect the printed wiring harness to the connector in order to avoid the half insertion of the printed wiring harness.

13. Install the center display in the reverse order of removal.


NOTE: DO NOT tighten the screws too tightly, but tighten them so that they do not come loose.

14. Verify the repair.


Page 7 of 23

Mazda6 Repair

1. Remove the 4 screws (1), then remove the connectivity master unit (CMU) (2) from the center display (3).





- 2. Place the cushion sheet (1) that the lens was wrapped on a working table.
- 3. Put on the rubber gloves.
- 4. Place the center display (2) on the cushion sheet (1) with the display side facing downward.





Page 8 of 23

5. Remove the 4 screws (1) that assemble the center display (2) and the bracket (3), then separate the bracket (3) and the cover panel (4).











6. Remove the 2 screws (1) on the back of the center display.




Page 9 of 23

7. Insert a tip of a flathead screwdriver (3) in the gap (2) between the lens and the rear cover.






Detail of (1)




Page 10 of 23

8. Pull up the rear cover with a flathead screwdriver (1) while being careful to not touch the connector, then remove the rear cover.


CAUTION: Be careful not to damage the circuit board and the connectors when removing the rear cover.





Pull the rear cover outward so that the cover does not touch the connectors.

Center display (joint with rear cover)



Rear cover (joint with center display)




Page 11 of 23

9. Remove the 4 screws (circled in yellow).



10. Push the locking tab (2) on the connector (1) to unlock it while pushing the circuit board, then remove the cable (FPC:






Page 12 of 23

NOTE: Pull out the cable by holding both side-edges of it to avoid damaging the cable.





- 11. Remove the center display from the lens.
- 12. Replace the lens with a modified one, reusing the center display

Replace the lens with a modified one.



Reuse the center display.



13. Assemble the center display in the reverse order of disassemble.


NOTE:

- DO NOT tighten the screws too tightly, but tighten them so that they do not come loose.
- · When attaching the cable to the circuit board, be careful not to engage with the connector half-fit.
- 14. Install the center display in the reverse order of removal.
- 15. Verify the repair.


Page 13 of 23

CX-5 Repair

1. Remove the 4 four screws (1), then remove the connectivity master unit (CMU) (2) from the center display (3).




- 2. Place the cushion material (1) that the lens was wrapped in, on a workbench.
- 3. Put on the rubber gloves.
- 4. Place the center display (2) on the cushion material (1) with the display side facing downward.




Page 14 of 23

5. Remove the 4 screws (1) that assemble the center display (2) and the bracket (3), then separate the bracket (3) and the cover panel (4).




6. Remove the 2 screws (1) that assemble the center display and the rear cover (2).



Page 15 of 23

- 7. Remove the rear cover according to the following steps.
 - There are 3 three fitting sections of the rear cover and the center display.
 - The number in the image below is the order in which to unhook the ribs.



Rear cover





Center display




Page 16 of 23


a. Unhook rib (1) by inserting the tip of a flathead screwdriver in the gap (2) between the lens and the rear cover below connectors (4), then unhooking the rib (3).








Rib (3) of the rear cover



Rib (3) of the rear cover



Hook (5) of the center display


Page 17 of 23

b. Unhook rib (2) by inserting the tip of a flathead screwdriver in the gap (2) between the lens and the rear cover, then unhooking the rib.




c. Unhook rib (3) by inserting the tip of a flathead screwdriver in the gap (3) between the lens and the rear cover, then unhooking the rib.






Page 18 of 23

8. Pull up the rear cover (1) carefully so that the rib (3) does not touch the connectors (2), then remove the rear cover.





Rear cover



Center display



Page 19 of 23

9. Remove the 4 screws shown below.




Bracket



Center display




10. Remove the cable (FPC: Flexible Printed Circuit) in order (1), (2), (3) as shown in the image below. **NOTE:** To unlock the connector, pull up the locking tab while holding the circuit board.




Page 20 of 23

ATTENTION: Pull out the cable by holding both side-edges to avoid damaging the cable.






Locked



Unlocked




- (1) Cable
- (2) Locking tab
- 11. Remove the center display from the lens.

Page **21** of **23**

12. Replace the lens with a modified one, but reuse the center display

Lens






13. Assemble the center display in the reverse order of disassembly.

NOTE:

- When attaching the cable to the circuit board, be sure the connection is secure.
- DO NOT use electric tools to tighten the screws. Overtightening the screws (circled in yellow in the following figures) may cause uneven brightness of the display. If uneven brightness occurs, loosen the screws and retighten them to the point to avoid coming loose.






Page 22 of 23





Example of the uneven brightness:



- 14. Install the center display in the reverse order of removal.
- 15. Verify the repair.

PARTS INFORMATION

	Parts Number	Description	Qty.	Notes
Mazda3	BHY1-61-1JZ	Display-Assembly (Repair Kit)	1 In	Includes a center display lens and antistatic rubber gloves.
Mazda6	GRY7-61-1JZ			
CX-5	K1Y3-61-1JZ			

WARRANTY INFORMATION

Vehicles outside of SSPB6, 09-037/21 and 09-003/22 VIN range, use normal warranty process.

Page 23 of 23