

LEVELING AND STABILIZATION

Purpose

This document outlines the procedures to install footpads on 8K hydraulic jacks.

Safety

Read and understand all instructions before installing or operating this product. Adhere to all safety labels.

WARNING

The unit must be supported according to the manufacturer's recommendations. Failure to do so may result in death or serious personal injury.

Resources Required

- Impact wrench
- 15/16" socket
- Footpad Kit PN 324269; contains footpad, bushing and bolt
- Torque wrench (Optional)

Procedures

1. Apply Loctite™ 263 High Strength Thread Locker (Red) to the footpad bolt.
2. Insert bolt through the bushing and footpad and thread bolt into bottom of jack (Fig. 1).
3. Tighten bolt with impact wrench and ensure the footpad is firmly attached without excessive movement.

NOTE: If an impact wrench is not available, torque the bolt to 132 ft-lbs to achieve tightness without excessive movement of the footpad.

NOTE: Do not try to remove the bolt once it is tightened. Removing the bolt could result in damage to the cylinder.

